

How to Set Up the Telephone Number(s) That You Want to Call

What you see on Display

NOT PROGRAMMED
PRESS KEYPAD #1

1

EMERGENCY CALLER
USP 1.0C

2

PROGRAM: NUMBERS

3

SELECT: 1-4
0 (DONE)

4

PAGER
1 (YES) 2(NO)

5

ENTER NUMBER
THEN PRESS *

6

SELECT: 1-4
0 (DONE)

7

PROGRAM: T-LINE
1 (YES) 2(NO)

Keys that You Press

Press [1]

Screen will
automatically
scroll from 1 to 2
then stop on 3

Press [1]

(For the 1st number)

Press [2]

See page 12 of user
manual for pager
programming

Type-in phone
number to call

Press [*]

2~4 for more numbers
goes back to ④
~~ OR ~~
Press [0]
(when done)

Press [2]

How to Set Up Your Outgoing Message That You Want to Send

What you see on Display

- 8 PROGRAM: OGM
1 (YES) 2(NO)
- 9 PRESS R
- 10 RECORDING
- 11 PLAY OGM
1 (YES) 2(NO)
- 12 ACCEPT
1 (YES) 2(NO)
- 13 PROGRAM: INPUT
1 (YES) 2(NO)
- 14 PROGRAM: MOM/CONT
1 (MOM) 2(CONT)
- 15 PROGRAM: NUMBERS
1 (YES) 2(NO)
- 16 OPERATE

Keys that You Press

Press [1]

Prepare to speak
clearly towards Unit

Press and
Hold [R]

Release [R] when
message is done.

Press [1]

Press [1]

Press [1]

Press [2]

Press [M]
(2 times)

WA-900 is now
ready for use.